


1

2



Nennmass		Toleranzklasse	Toleranzklasse	Toleranzklasse
über	bis	+/- P1	+/- P2	+/- P3
0	1.6	0.2	0.2	0.4
1.6	4	0.2	0.3	0.4
4	6.3	0.2	0.4	0.5
6.3	10	0.3	0.5	0.6
10	25	0.3	0.6	0.8
25	40	0.4	0.8	1
40	63	0.5	1	1.5
63	100	0.6	1.2	2
100	160	0.8	1.4	2.5
160	250	1	1.6	3
250	400	1.6	2.5	5
400		0.5%	0.8%	1.5%



**Vibraplast AG**  
 CH-8355 Aadorf  
 Tel. +41(0)52 368 00 50  
 info@vibraplast.ch  
 www.vibraplast.ch

Geändert:

Datum:

Visum:

Erstellt: Urs Koradi/UKO  
 Datum: 21.09.2007

Massstab: ./.

Format: A 4



CAD-SolidWorks

ED/EF

Name GRENZABMASSE FÜR PLATTEN, ZUSCHNITTE, STANZARTIKEL

ZNr. ISO 3302-1 P

Ausgabe

01